Setting Up a Windows Web Server on EC2

1. Launch the EC2 Instance

- Create and launch an EC2 instance with a Windows operating system.
- Ensure that RDP and HTTP ports are open in the security group.

2. Access the Instance

 Connect to the instance using Remote Desktop Protocol (RDP).

3. Install Web Server (IIS) Role

- Open Server Manager from the Start menu.
- Click on Add roles and features.
- Select Role-based or feature-based installation and click Next.
- Choose the target server and click Next.
- Select Web Server (IIS) and click Add Features when prompted.
- Click Next several times to proceed with the default settings.
- Click Install to start the installation, then click Close when finished.

4. Prepare the Web Root Directory

- Open File Explorer and navigate to C:\inetpub\wwwroot.
- Delete any existing files in this directory.

5. Create a Simple HTML File

- Open Notepad and create a simple HTML file.
- Add your desired content.
- Save the file as index.html in the C:\inetpub\wwwroot directory.
- When saving, select **All Files** as the file type to ensure it's saved as an HTML file, not a text file.
- Delete the Notepad file after saving.

Your Windows web server is now set up and ready to serve the index.html file. You can test it by accessing the public IP address of your EC2 instance in a web browser.